



**LIGHT^{MY}
BRICKS**



**LEGO[®] EIFFEL TOWER #10307
LIGHT KIT**

INSTALLATION GUIDE

Part 1 of 2

Light My Bricks



LEGO® EIFFEL TOWER 10307 INSTALLATION GUIDE

Hi There!

We're here to help you get started on the LEGO®

Eiffel Tower 10307 Light Kit.

This PDF details the instructions for the LED light kit only.

If you run into any issues, please refer to the troubleshooting section towards the end of this guide.

Have fun and enjoy!

INSTALLATION GUIDE





PACKAGE CONTENTS:

* Indicates components which include spares

Individual Bags



- 28x White 30cm Micro Bit Light *
- 8x White 15cm Micro Bit Light
- 2x RGB 15cm Bit Light 2.0
- 15x RGB Strip Light 2.0 *
- 2x White 15cm Bit Light
- 1x 2Pin-3Pin 30cm Connecting Cable
- 1x 120cm Connecting Cable

Connecting Cables



- 1x 5cm Connecting Cable
- 4x 15cm Connecting Cable
- 8x 30cm Connecting Cable *
- 5x 50cm Connecting Cable *

RGB Connecting Cables



- 10x RGB 15cm Connecting Cable
- 6x RGB 30cm Connecting Cable *

Mixed Components 1



- 4x 2-Port Expansion Board
- 3x 6-Port Expansion Board
- 36x Adhesive Square *

Mixed Components 2



- 5x 8-Port Micro Expansion Board *

Mixed Components 3



- 2x IR Switch Board
- 1x 3Pin Sparkle Effects Control Board

USB Power Cable



- 2x USB Power Cable
(Power Source not Included)



PACKAGE CONTENTS:

Mixed Components 4



8x Plate, Round 1x1 Open Stud - Black
 4x Plate, Round 1x1 with Bar Handle - Black
 4x Tile, Modified 1x1 with Open O Clip - Black
 4x Bracket 1x1 - 1x1 Inverted - Dark Bluish Gray

Mixed Components 5



8x Brick 1x2 - Black

Mixed Components 6



8x Tile 1x6 - Black

Mixed Components 7



4x Plate 1x6 - Black

Light String Warm White 15 LED 3 Pin



6x Light String 15 LED 3Pin - Warm White

Light String Warm White 15 LED 3 Pin



5x Light String 15 LED 3Pin - Warm White

RGB Components





1x RGB Remote Control
 3x RGB Control Board
 1x RGB 6-Port Expansion Board

Contents

Before You Begin	5
Blueprint	11
Instructions: Part 1	15
Troubleshooting	91
Contact	95



Before You Begin



Laying cables in between and underneath bricks

Cables can fit in between and underneath LEGO® bricks, plates, and tiles providing they are laid correctly between the LEGO® studs. Do NOT forcefully join LEGO® together around cables; instead ensure they are laying comfortably in between each stud.

CAUTION: Forcing LEGO® to connect over a cable can result in damaging the cable and light.




Connecting Cable Connectors To Expansion Boards

Take extra care when inserting connectors to ports of Expansion Boards. Connectors can be inserted only one way. With the expansion board facing up, look for the soldered “=” symbol on the left side of the port. The connector side with the wires exposed should be facing toward the soldered “=” symbol as you insert into the port. If a plug won’t fit easily into a port connector, do not force it.


Incorrectly inserting the connector can result in bent pins inside the port or possible overheating of the expansion board when connected.

Before You Begin



Connecting Cable Connectors To Strip Lights

Take extra care when inserting connectors to ports on the Strip Lights. Connectors can be inserted only one way. With the Strip Light facing up, ensure the side of the connector with the wires exposed is facing down. If a plug won't fit easily into a port connector, don't force it. Doing so will damage the plug and the connector.




Connecting Micro Cable Connectors To Micro Expansion Board Ports

Take extra care when inserting the micro connectors to micro ports of Micro Expansion Boards. Connecting Micro Bit Lights to Micro Expansion Boards is similar to connecting lights and cables to Strip Lights. With the expansion board facing up, ensure the side of the connector with the wires exposed is facing down. If a plug won't fit easily into a port connector, do not force it. Use your fingernail to push the plastic part of the connector to the micro port.

Before You Begin

Installing Bit Lights Under Lego® Bricks And Plates

When installing Bit Lights under LEGO® pieces, ensure they are placed the correct way up (Yellow LED component exposed). You can either place them directly on top of LEGO® studs or in between.



Before You Begin

The Symbols Used In This Guide

When going through the following guide you will come across symbols and formats that will assist with the installation of your light kit. Take notice of them as each has a specific purpose.

Light Kit Component

This is the most important image format as it indicates which part to use from the Light Kit. Make sure you pay close attention to which part is shown.

White 30cm Bit Light



Connect

Used when you need to connect a LEGO piece or LMB component.



Disconnect

Used when you need to remove a LEGO piece/ section or LMB component.



Directional

Used to show where to route cables, place components, or move them.



Bend/Pivot

Used when a component needs to be bent, or part folded or pivoted.



Turn/ Flip

Will be found in the top left corner when the set needs to be rotated or flipped.



Twist/ Braid

Seen when a set of cables need to be grouped and twisted together.



Power On Test

Found at the end of a major step to test the lights. Will be located in the top left corner.



Note

Notes will be found alongside the instruction photos and explain what to do.



Before You Begin

Repeat Step

Repeat the previous step eg. Make a spotlight, then make a second spotlight.

x2

Connect Focus

Used to highlight a hard to see area where a component is being connected.



Disconnect Focus

Used to highlight a hard to see area where a component is being disconnected.



General Focus

Used to highlight a hard to see area where a component needs to be acted on.



General Note

This is a sample note that is used anywhere in this guide. It will explain a difficult section where photos are hard to illustrate or easily confused.

Connect Note

The green coloured note is used when the topic focuses on a component being connected, like the shown Power Bank.


Disconnect Note

The red coloured note is used when the topic focuses on a component being disconnected or like here, the removed pieces.



NOTE

Take the 5cm Connecting Cable from the 4-Port Micro Expansion Board and route it into the "IN" port of the Flicker Effects Board



NOTE

Connect to a 5V USB Power Bank, 5V USB Wall Adaptor, or USB to AA Battery Pack (sold separately)



NOTE

You should have these parts left over that were removed from the LEGO set






BLUEPRINT: *Top Level*

Viewing Tower


Top Level





BLUEPRINT: *Middle Level*


Middle Level





BLUEPRINT: *Bottom Level*

Bottom Level





INSTRUCTIONS

To ensure a smooth installation of your light kit, please read and follow each step carefully. If you run into any issues, please refer to the [online troubleshooting guide](#).



Wenn Sie Probleme mit Ihrem Light My Bricks-Set haben, sehen Sie sich unser Video zur Fehlerbehebung an oder lesen Sie die Auflistung der häufigsten Ursachen, die Ihnen bei der Fehlersuche helfen hier.



Si vous rencontrez des problèmes avec votre kit Light My Bricks, regardez notre vidéo de dépannage ou consultez la liste des causes les plus fréquentes pour vous aider à les résoudre ici.




Se si verificano problemi con il set Light My Bricks, guardare il nostro video per la risoluzione dei problemi o leggere l'elenco delle cause più comuni per la risoluzione dei problemi qui.

1

NOTE

Ensure front side has the Yellow elevator on the left and the Red on the right.





2





3

4





NOTE

Use the LEGO Brick Separator Tool or similar to pry apart plates.











5







6












USB Power Cable



8-Port Micro Expansion Board






7




8



15cm Connecting Cable












 **NOTE**

Position the Expansion Board as shown and route the cable. This will allow the right amount of cable length.




9





10



White 15cm Micro Bit Light



NOTE





Position the Micro Bit Light LED sideways as shown; this will allow it to fit inside of the lamp posts.




NOTE
To check if the light is positioned correctly, remove the black cap and look for the Micro Bit Light LED.









11






NOTE
Ensure the cable is placed in between the studs and coming out from the indicated location.




12





13





 **NOTE**

Run the cables to the side of the brown piece, ensure it is under the piece when placed down.











14



 **NOTE**

Press down on the middle of the brown piece first, then press down where indicated.





NOTE


Connect to a 5V USB Wall Adaptor (sold separately). A power bank or battery pack is not recommended to power this set.






NOTE

Testing the set regularly is encouraged to ensure all of the lights are working when completing each step.


15




White 15cm Micro Bit Light













16






White 30cm Micro Bit Light





17



18



White 30cm Micro Bit Light






19










20









21


22



 **NOTE**

Run all of the Micro Bit Light cables about halfway through the red circle brick.



 **NOTE**

Place the green plate in an upright position, this will allow you to connect the cables underneath.






23






NOTE

If you have trouble attaching the Micro Bit Light cables to the Micro Expansion Board, remove the connecting cable, then reattach after.




24



NOTE

Position the green plate as shown, and ensure all of the cables are clear of the studs and placed in the empty spaces.



NOTE

Rest the green plate down in the original position, but do not press down yet.



NOTE

Press down the centre of the green plate first, then press down each of the brown tile sections indicated.



NOTE

Then press down the remaining sections by pressing on the edge of the brown plate of each. Ensure you do not press too hard.










NOTE

The green plate will be slightly raised but this is normal. There are several cables underneath and making it flat will break them.



25












26






8-Port Micro Expansion Board

27













NOTE








Hold the Micro Expansion Board in the following position, before securing the Connecting Cable in place






28







29









30







White 30cm Micro Bit Light





31




32





33














White 30cm Micro Bit Light



34





35




White 30cm Micro Bit Light





36









37








White 30cm Micro Bit Light





White 30cm Micro Bit Light










39



40







NOTE



Connect to a 5V USB Wall Adaptor (sold separately). A power bank or battery pack is not recommended to power this set.




! If you experience any issues with the lights not working and suspect an issue with a component, please try a different port on the expansion board to verify where the fault lies (with the light or expansion board). To correct any issues with expansion board ports, please view the section addressing expansion board issues in our troubleshooting section. i



41








42





43




8-Port Micro Expansion Board










NOTE

Hold the Micro Expansion Board in this position, then fix the cable down and let go.













30cm Connecting Cable





44












45









White 30cm Micro Bit Light





46











47




White 15cm Micro Bit Light





48










White 30cm Micro Bit Light






49



50








White 30cm Micro Bit Light




51




White 30cm Micro Bit Light








White 30cm Micro Bit Light



52






53






White 30cm Micro Bit Light








54





55









NOTE

Connect to a 5V USB Wall Adaptor (sold separately). A power bank or battery pack is not recommended to power this set.




! If you experience any issues with the lights not working and suspect an issue with a component, please try a different port on the expansion board to verify where the fault lies (with the light or expansion board). To correct any issues with expansion board ports, please view the section addressing expansion board issues in our troubleshooting section. i




56







8-Port Micro Expansion Board





57







White 15cm Micro Bit Light









58







White 30cm Micro Bit Light




59












60






30cm Connecting Cable











61



White 15cm Micro Bit Light




62







63

64




65










White 30cm Micro Bit Light



67



68


















White 30cm Micro Bit Light






69





70



2x Adhesive Square





NOTE



Connect to a 5V USB Wall Adaptor (sold separately). A power bank or battery pack is not recommended to power this set.



! If you experience any issues with the lights not working and suspect an issue with a component, please try a different port on the expansion board to verify where the fault lies (with the light or expansion board). To correct any issues with expansion board ports, please view the section addressing expansion board issues in our troubleshooting section. i



71




IR Switch Board




NOTE

Connect the loose 30cm Connecting Cable into the "+5V" port of the IR Switch Board.




50cm Connecting Cable



NOTE




Connect a 50cm Connecting Cable into the "OUT A" port of the IR Switch Board.








72


NOTE

Wrap the 50cm Connecting Cable up the tower leg. Follow the guide photos as closely as possible.


73




6-Port Expansion Board



74




5cm Connecting Cable



NOTE

Connect a 5cm Connecting Cable into the "OUT B" port of the IR Switch Board.








3Pin Sparkle Effects Control Board




NOTE








Connect the other end of the 5cm Connecting Cable into the "+5V" port of the 3Pin Sparkle Effects Control Board.



75




30cm Connecting Cable




RGB IR Control Board







 **NOTE**

Connect the 5cm Connecting Cable from the 4-Port Micro Expansion Board into the "IN" port of the Flicker Effects Board






76










NOTE

Twist the 50cm Connecting Cable from Step 71 only.





77












78



79


NOTE

Take one of the two loose 15cm RGB Connecting Cables from Step 77 and thread as shown.





80



NOTE


Take the end of the loose 30cm RGB Connecting Cable and thread it through.



Tile 1x6 - Black






Brick 1x2 - Black




81




RGB Strip Light 2.0





 **NOTE**

Take the loose 15cm RGB Connecting Cable from Step 77 and thread it as shown.




Tile 1x6 - Black



Brick 1x2 - Black





RGB Strip Light 2.0


RGB 30cm Connecting Cable






83



84



Brick 1x2 - Black

RGB Strip Light 2.0

85

86

NOTE

Connect to a 5V USB Wall Adaptor (sold separately). A power bank or battery pack is not recommended to power this set.


RGB IR Remote

NOTE

Use the included RGB IR Remote to Control the RGB Strip Lights via the RGB Board. Point the remote at the board indicated below.



NOTE

Press the R, G, and B buttons on the Remote to change the Strip Lights to Red, Green, and Blue to test if they are working.






! If you experience any issues with the lights not working and suspect an issue with a component, please try a different port on the expansion board to verify where the fault lies (with the light or expansion board). To correct any issues with expansion board ports, please view the section addressing expansion board issues in our troubleshooting section. **i**

87




Light String 15 LED 3Pin - Warm White






NOTE

Connect the Light String 15 LED 3Pin to the "OUT" port of the 3Pin Sparkle Effects Control Board.






Adhesive Square



88

NOTE

Wrap the Light String up the tower leg. Follow the guide photos as closely as possible.







89




Light String 15 LED 3Pin - Warm White




90






Light String 15 LED 3Pin - Warm White





91





92



Light String 15 LED 3Pin - Warm White





NOTE

Leave the end of the String Light loose for now. It will be connected to the second level of the Eiffel Tower when it is completed later.



NOTE

Connect to a 5V USB Wall Adaptor (sold separately). A power bank or battery pack is not recommended to power this set.



NOTE

Use the RGB Remote to switch between the RGB Mode and Sparkle Mode with the ON and OFF buttons. Point it at the IR Switch Board when pressing.



NOTE

After 30 seconds the String Lights flash rapidly for 30 seconds then back to static. Avoid staring at the effect as it may cause discomfort to some.

NOTE

You should have these parts left over that were removed from the LEGO set so far.



! If you experience any issues with the lights not working and suspect an issue with a component, please try a different port on the expansion board to verify where the fault lies (with the light or expansion board). To correct any issues with expansion board ports, please view the section addressing expansion board issues in our troubleshooting section. **i**

NOTE

This concludes Part 1 of the Eiffel Tower Guide. To continue, please click the box to download Part 2.

Click me!

Part 2

Links to instructions portal page



TROUBLESHOOTING

Light My Bricks lighting kits contain individual components that are very small and can be easily damaged if not handled correctly.

To prevent unnecessary damage to components, we highly recommend that the User Guide section, **“Important things to note”** is read carefully. Follow the handling procedures in the User Guide to help prevent faults and damages to your Light My Bricks components.

If you are experiencing issues with your Light My Bricks set, watch our troubleshooting video or read on for a list of common causes to help you troubleshoot.



Wenn Sie Probleme mit Ihrem Light My Bricks-Set haben, sehen Sie sich unser Video zur Fehlerbehebung an oder lesen Sie die Auflistung der häufigsten Ursachen, die Ihnen bei der Fehlersuche helfen hier.



Si vous rencontrez des problèmes avec votre kit Light My Bricks, regardez notre vidéo de dépannage ou consultez la liste des causes les plus fréquentes pour vous aider à les résoudre ici.



Se si verificano problemi con il set Light My Bricks, guardare il nostro video per la risoluzione dei problemi o leggere l'elenco delle cause più comuni per la risoluzione dei problemi qui.

Troubleshooting

Firstly, ensure that the batteries have power using a battery charge gauge.


If the batteries have no power, replace the batteries.

If the batteries still have power, check to see if the batteries have been inserted correctly into the battery pack.

Check for AA batteries using the AA battery pack

Inside the battery pack are symbols indicating which direction the AA battery should be inserted. The flat side of the battery should be paired with the spring side of the battery pack.

If the batteries have been installed correctly and your kit still isn't operating correctly, the next step is to check the wiring.



Troubleshooting

Check Your Wires



In order for Light My Bricks components to fit in between and underneath LEGO® bricks, the components need to be very small. Due to this nature, Light My Bricks components can be easily damaged when not handled correctly.

Be careful when removing unpacked components out of the packaging and ensure not to forcibly pull at the wires as this can damage the soldering that attach the wires to the LEDs.

If the wiring is detached from the LED itself, the light will not operate.

When connecting lights to your LEGO® set, check that there are no pinched wires underneath or in between bricks and plates.

When the wires are pinched and the exposed wires are touching each other, this can cause a crosswire and the lights to not function correctly.




Troubleshooting

Check Your Expansion Board Ports / Strip Light Ports / Effects Board Ports

It is important to note that connectors can only be inserted to the expansion board, strip light, or effects board ports in one direction.

Forcibly inserting connectors in the incorrect direction will result in damaging the pins inside each of the ports on your component board.



Not only will a light connected to the damaged port not work, but if the pins inside the port are bent to a point they are touching each other, this can result in all other lights in the system to stop working. This is a short circuit.



A short circuit can also result in overheating of the board, cable or batteries. If you suspect a short circuit, **DISCONNECT POWER IMMEDIATELY**. Batteries can fail, catch fire, or even explode if left connected to a short circuit for too long.

If you suspect you have a faulty component due to a bent pin, try the following steps:

If you look carefully inside each of the ports, each port contains 2 small pins that should be straight. You will be able to identify a faulty port if it has any bent pins.





CONTACT US

If you have an enquiry regarding the online shop, our products or a general enquiry please refer to our Frequently Asked Questions webpage.

Alternatively, you can contact our Customer Services team by visiting our online support portal.

support.lightmybrick.com

We thank you for purchasing this product and hope you enjoy!



lightmybricks.com